

USER INSTRUCTIONS

PHILIPS LIGHTING COMPANY 11/29/01

SUNLAMP - DANGER - ULTRAVIOLET RADIATION - FOLLOW INSTRUCTIONS

INSTRUCTIONS ACCOMPANYING THE SUNLAMP PRODUCT SHOULD ALWAYS BE FOLLOWED TO AVOID OR MINIMIZE POTENTIAL INJURY. THE FOLLOWING INSTRUCTIONS ON LAMP COMPATIBILITY (EQUIVALENCE) OF PHILIPS LAMPS ARE IN COMPLIANCE WITH "POLICY ON LAMP COMPATIBILITY", 21 CFR 1040.20 (c) (2) (iii).

PHILIPS CLEO Advantage 100W

MODEL IDENTIFICATION: EQUIVALENT TO: PER 21 CFR 1040.20 (c) (2) (iii)

PHILIPSCLEO Advantage 100W F71T12 Bi-Pin Made in Holland	Genesis 105W Plus F71T12 BP-105W Preheat Bi-Pin Midday Sun (5.0) F71T12-BL HO Beach Sun (6.5) F71T12-BL HO Cosmolux ESP 100W F71T12 RS/BP F71 Puretan S+ Bi -Pin Super Sun SX SS71/BP/ X6500
--	---

CLEO Advantage 100W F73T12 RDC Made in Holland	Genesis Plus 105W F73T12 105W Rapid Start RDC Midday Sun (5.0) F73T12-BL HO Beach Sun (6.5) F73T12-BL HO Cosmolux ESP 100W F73T12 RDC F73 Puretan S+ RDC GENESIS 120W F73-T12-HO-120W Rapid Start RDC by Voltarc GENESIS 120W F73-T12-HO-120W Rapid Start RDC by Light Sources
--	--

SUNLAMP - DANGER - ULTRAVIOLET RADIATION - FOLLOW INSTRUCTIONS USE ONLY IN FIXTURE EQUIPPED WITH A TIMER. SEE INSTRUCTIONS AT THE BOTTOM OF THIS PAGE

REMINDER - ALWAYS RETAIN THESE USER INSTRUCTIONS FOR FUTURE REFERENCE AND LAMP COMPATIBILITY INFORMATION

AVOID OVEREXPOSURE. As with natural sunlight OVEREXPOSURE can cause eye and skin injury and allergic reactions. Repeated exposure may cause premature aging of the skin and skin cancer. WEAR PROTECTIVE EYEWEAR: FAILURE TO MAY RESULT IN SEVERE BURNS OR LONG TERM INJURY TO THE EYES. Medications or cosmetics **may** increase your sensitivity to the ultraviolet radiation. Consult physician before using sunlamp if you are using medications or have a history of skin problems or believe yourself especially sensitive to sunlight. If you do not tan in the sun, you are unlikely to tan from the use of this product.

Philip Lighting Company, 200 Franklin Square Drive, Somerset, NJ 08875-6800