

# USER INSTRUCTIONS

PHILIPS LIGHTING FEBRUARY 2002

## SUNLAMP - DANGER - ULTRAVIOLET RADIATION - FOLLOW INSTRUCTIONS

INSTRUCTIONS ACCOMPANYING THE SUNLAMP PRODUCT SHOULD ALWAYS BE FOLLOWED TO AVOID OR MINIMIZE POTENTIAL INJURY. THE FOLLOWING INSTRUCTIONS ON LAMP COMPATIBILITY (EQUIVALENCE) OF PHILIPS LAMPS ARE IN COMPLIANCE WITH "POLICY ON LAMP COMPATIBILITY", 21 CFR 1040.20 (c) (2) (iii).

### *PHILIPS CLEO Advantage 140W -R*

MODEL IDENTIFICATION:      EQUIVALENT TO: PER 21 CFR 1040.20 (c) (2) (iii)

PHILIPS CLEO Advantage    F59 Puretan SPECTRALARIUM VH0/R+ RDC<sup>1</sup>  
140W R F59T12 Bi-Pin      Made in Holland

**SUNLAMP - DANGER - ULTRAVIOLET RADIATION - FOLLOW INSTRUCTIONS USE ONLY IN FIXTURE EQUIPPED WITH A TIMER. SEE INSTRUCTIONS AT THE BOTTOM OF THIS PAGE**

**REMINDER - ALWAYS RETAIN THESE USER INSTRUCTIONS FOR FUTURE REFERENCE AND LAMP COMPATIBILITY INFORMATION**

**AVOID OVEREXPOSURE.** As with natural sunlight OVEREXPOSURE can cause eye and skin injury and allergic reactions. Repeated exposure may cause premature aging of the skin and skin cancer. WEAR PROTECTIVE EYEWEAR: FAILURE TO MAY RESULT IN SEVERE BURNS OR LONG TERM INJURY TO THE EYES. Medications or cosmetics **may** increase your sensitivity to the ultraviolet radiation. Consult physician before using sunlamp if you are using medications or have a history of skin problems or believe yourself especially sensitive to sunlight. If you do not tan in the sun, you are unlikely to tan from the use of this product.

Philip Lighting Company, 200, Franklin Square Drive, Somerset, NJ, 08875-6800, USA

---

<sup>1</sup> RDC end caps to be mounted on Philips equivalent

